

5 – Remove Factory Radio

Remove the OEM Radio and prepare the Myron and Davis Unit for installation by following the steps below.

Note: Inspect all fasteners and brackets for damage. Replace as necessary before the installation process is started

Step 1. Remove the mounting bolts on the driver's side



Step 2. Remove the mounting bolts on the passenger side.



Step 3. Remove the mounting brackets from the factory radio.



Step 4. Install the mounting brackets on the M&D radio.

