

Volvo left front
drivers seat
mounting bracket,
looks to be solid
or welded on.
Grind off drill two
7/16" holes and
mount Prius
bracket here with
two 7/16" bolts.

