

Toyota : Prius : 2004-09

Front : Left

Actual	Before	Specified Range
-0.3°	-0.3°	-1.3° 0.2°
		2.4° 3.9°
0.03°	-0.57°	-0.10° 0.10°
		11.8° 13.3°
		10.5° 13.5°

Camber
Caster
Toe
SAI
Included Angle
Turning Angle Diff.

Front : Right

Actual	Before	Specified Range
-0.8°	-0.8°	-1.3° 0.2°
		2.4° 3.9°
0.03°	0.69°	-0.10° 0.10°
		11.8° 13.3°
		10.5° 13.5°

Front

Cross Camber
Cross Caster
Cross SAI
Total Toe
Cross Turn Diff.

Actual	Before	Specified Range
0.5°	0.5°	-0.8° 0.8°
		-0.8° 0.8°
		-0.8° 0.8°
0.05°	0.12°	-0.20° 0.20°

Rear : Left

Actual	Before	Specified Range
-1.3°	-1.3°	-2.0° -1.0°
0.12°	0.13°	0.03° 0.28°

Camber
Toe

Rear : Right

Actual	Before	Specified Range
-1.4°	-1.4°	-2.0° -1.0°
0.22°	0.22°	0.03° 0.28°

Rear

Cross Camber
Total Toe
Thrust Angle

Actual	Before	Specified Range
0.1°	0.1°	-0.5° 0.5°
0.34°	0.35°	0.05° 0.55°
-0.05°	-0.05°	