

## CUSTOMIZE PARAMETERS

### NOTICE:

Basically, these buzzers should be set on for safety driving. However, only if it is necessary to set the buzzer off for some reason, perform the following procedures.

### Procedure

Steps	Back-up Warning Buzzer	Driver's Seat Belt Buzzer	Front Passenger's Seat Belt Buzzer
1	Turn power switch ON (IG)	Turn power switch ON (IG)	Turn power switch ON (IG)
2	Press ODO / TRIP switch until odometer displays "ODO"	Press ODO / TRIP switch until odometer displays "ODO"	Press ODO / TRIP switch until odometer displays "ODO"
3	Turn power switch OFF	Turn power switch OFF	Turn power switch OFF
4	Turn power switch ON (IG) while depressing brake pedal. Check that combination meter displays "READY"	Turn power switch ON (IG) while depressing brake pedal. Check that combination meter displays "READY"	Turn power switch ON (IG) while depressing brake pedal. Check that combination meter displays "READY"
5	After turning power switch ON (IG), press ODO / TRIP switch within 6 seconds, and hold it down for 10 seconds or more	After turning power switch ON (IG), press ODO / TRIP switch within 6 seconds, and hold it down for 10 seconds or more.	Sit in front passenger seat. After turning the power switch ON (IG), press ODO / TRIP switch within 6 seconds, and hold it down for 10 seconds or more.
6	Continue holding down ODO / TRIP switch, move shift lever to R and press P switch	Continue holding down ODO / TRIP switch, fasten driver seat belt	Continue holding down ODO / TRIP switch, fasten front passenger seat belt
7	Check that odometer displays either "b-on" or "b-off"	Check that odometer displays either "b-on" or "b-off"	Check that odometer displays either "b-on" or "b-off"
8	Press ODO / TRIP switch to change display to "b-off"	Press ODO / TRIP switch to change display to "b-off"	Press ODO / TRIP switch to change display to "b-off"
9	Turn power switch OFF	Turn power switch OFF	Turn power switch OFF
10	Turn power switch ON (IG) while depressing brake pedal. Check that combination meter displays "READY"	Turn power switch ON (IG) while depressing brake pedal. Check that combination meter displays "READY"	Turn power switch ON (IG) while depressing brake pedal. Check that combination meter displays "READY"
11	Check that no buzzer sounds when shift lever is in "R"	Check that no buzzer sounds	Check that no buzzer sounds when sitting on front passenger seat

### HINT:

\*: "b-off" indicates that the buzzer is OFF. "b-on" indicates that the buzzer is ON. The buzzer cancel setting will be finished (the odometer will display "ODO") if the ODO / TRIP switch is not operated for 10 seconds or more. In this case, perform step 11 to check that buzzer cancel setting is complete. If it is not complete, start from step 1 again.

### NOTICE:

When either the battery cable or the combination meter connector is disconnected, these buzzers are set on.