

CAMERA LOCKPICK HARDWARE

This is the Harness Missing

CAMERA LOCKPICK
AUDIO HARNESS

Have this Harness

CAMERA LOCKPICK
CONTROLLER HARNESS

CAMERA LOCKPICK
VIDEO HARNESS & OPTIONS

STANDARD SINGLE CAMERA INPUT

CONNECT REAR CAM POWER TO
LOCKPICK BLUE CAMERA 12V+

CONNECT REAR CAM GROUND TO
LOCKPICK BLACK GROUND CONNECTION

VIDEO "Y" ADAPTER

OPTIONAL MULTIPLE VIDEO INPUTS
USING "Y" ADAPTER OR VIDEO SWITCH

OPTIONAL VIDEO SWITCH
V2SW-C

OPTIONAL VIDEO SWITCH
CONNECTION TO LOCKPICK CONTROLLER

CAMERA GROUND
CAMERA 12V OUTPUT

OPTIONAL VIDEO SWITCH
CONNECTION

2ND VIDEO INPUT

REVERSE CAMERA

2ND VIDEO INPUT

REVERSE CAMERA

