

10 Pin (White)					
A / 1	B / 2		C / 3	D / 4	
Lite Green	Pink		Red	Black	
+	+		+	+	
Right Front Speaker	Left Front Speaker		Radio Ignition (Remote)	Radio 12V (Battery)	
E / 5	F / 6	G / 7	H / 8	I / 9	J / 10
Blue	Purple	Brown			Lite Green
-	-	-			+
Right Front Speaker	Left Front Speaker	Ground	Not Used	Not Used	Radio illum (Parking Lights)

6 Pin (White)			
K / 1		L / 2	
Red		Black	
+		+	
Right Rear Speaker		Left Rear Speaker	
M / 3	N / 4	O / 5	P / 6
White		White	Yellow
-		-	-
Right Rear Speaker	Not Used	Radio Illumination (Dimmer)	Left Rear Speaker