


STARTING



PRIUS

POWERED
BY


HYBRID
SYNERGY
DRIVE



VALET INSTRUCTIONS


Affix to key ring
and present to valet.

1



Insert key

2



Depress brake pedal + Press "Power" button

3



You may begin driving after the
"READY" light remains on.

OVER

SHIFTING


1




Depress
the brake pedal

+

2



3



Check display to
confirm shift
position.

PARKING

1



Press
"P" Park button

2



Press
"POWER" button

3



Pull out
key

