

PROBLEM SYMPTOMS TABLE

HINT:

- Use the table below to help determine the cause of the problem symptom. The potential causes of the symptoms are listed in order of probability in the "Suspected area" column of the table. Check each symptom by checking the suspected areas in the order they are listed. Replace parts as necessary.
- Inspect the fuses and relays related to this system before inspecting the suspected areas below.

Front wiper and washer system

| Symptom | Suspected area | See page |
|--|---|----------|
| Both front wipers and washer systems do not operate. | 1. Windshield wiper switch | WW-29 |
| | 2. Wire harness or connector | - |
| Front wipers do not operate when windshield washer is normal. | 1. WIP fuse | - |
| | 2. Windshield wiper switch | WW-29 |
| | 3. Windshield wiper motor | WW-14 |
| | 4. Wire harness or connector | - |
| Front wipers do not operate in LO or HI. | 1. Windshield wiper switch | WW-29 |
| | 2. Windshield wiper motor | WW-14 |
| | 3. Wire harness or connector | - |
| Front wipers do not operate in INT. | 1. Windshield wiper switch | WW-29 |
| | 2. Windshield wiper motor | WW-14 |
| | 3. Wire harness or connector | - |
| Windshield washer motor does not operate. | 1. WSH fuse | - |
| | 2. Windshield wiper switch | WW-29 |
| | 3. Windshield washer motor and pump | WW-10 |
| | 4. Wire harness or connector | - |
| Front wipers do not operate when jet of washer fluid is emitted with washer switch on. | 1. Windshield wiper switch | WW-29 |
| | 2. Windshield wiper motor | WW-14 |
| | 3. Wire harness or connector | - |
| Jet of washer fluid is not emitted when windshield washer motor is normal. | 1. Washer hose and nozzle | - |
| Wiper blade does not return or return position is wrong when windshield wiper switch is off. | 1. Windshield wiper arm installation position | WW-15 |
| | 2. Windshield wiper motor | WW-14 |
| | 3. Wire harness or connector | - |

Rear wiper and washer system

| Symptom | Suspected area | See page |
|--|-------------------------------------|----------|
| Both rear wiper and washer systems do not operate. | 1. Windshield wiper switch | WW-29 |
| | 2. Wire harness or connector | - |
| Rear wiper does not operate in INT or ON. | 1. Windshield wiper switch | WW-29 |
| | 2. Rear wiper motor | WW-22 |
| | 3. Wire harness or connector | - |
| Rear washer motor does not operate. | 1. WSH fuse | - |
| | 2. Windshield wiper switch | WW-29 |
| | 3. Windshield washer motor and pump | WW-11 |
| | 4. Wire harness or connector | - |
| Jet of washer fluid is not emitted when rear washer motor is normal. | 1. Washer hose and nozzle | - |