

**SEARS AUTOMOTIVE CENTER  
#6332  
HOBART IN.**

**ALIGNMENT BAY #5  
THANK YOU AND COME AGAIN**

Name \_\_\_\_\_  
 Address \_\_\_\_\_  
 Telephone \_\_\_\_\_  
 Vehicle (VIN) \_\_\_\_\_  
 License \_\_\_\_\_  
 Technician \_\_\_\_\_  
 Mileage \_\_\_\_\_  
 Time Printed 3/1/09 4:22 PM

Toyota : Prius : 2004-07

Front : Left

Actual	Before	Specified Range	
-1.2°	-1.2°	-1.3°	0.2°
3.9°	3.9°	2.4°	3.9°
0.00°	-0.08°	-0.10°	0.10°
12.7°	12.7°	11.8°	13.3°
11.5°	11.5°	10.5°	13.5°
.....	.....	.....	.....

Camber  
 Caster  
 Toe  
 SAI  
 Included Angle  
 Turning Angle Diff.

Front : Right

Actual	Before	Specified Range	
0.0°	0.0°	-1.3°	0.2°
3.1°	3.1°	2.4°	3.9°
0.02°	0.21°	-0.10°	0.10°
13.3°	13.3°	11.8°	13.3°
13.3°	13.3°	10.5°	13.5°
.....	.....	.....	.....

Front

	Actual	Before	Specified Range	
Cross Camber	-1.3°	-1.2°	-0.8°	0.8°
Cross Caster	0.9°	0.9°	-0.8°	0.8°
Cross SAI	-0.6°	-0.6°	-0.8°	0.8°
Total Toe	0.02°	0.14°	-0.20°	0.20°
Cross Turn Diff.	.....	.....	.....	.....

Rear : Left

Actual	Before	Specified Range	
-1.2°	-1.2°	-2.0°	-1.0°
0.49°	0.50°	0.03°	0.28°

Camber  
 Toe

Rear : Right

Actual	Before	Specified Range	
-2.5°	-2.5°	-2.0°	-1.0°
0.07°	0.06°	0.03°	0.28°

Rear

	Actual	Before	Specified Range	
Cross Camber	1.4°	1.4°	-0.5°	0.5°
Total Toe	0.55°	0.55°	0.05°	0.55°
Thrust Angle	0.21°	0.22°	.....	.....

The steering wheel is currently level.