

2010 Prius Maintenance Schedule (Canadian, based on Owner's Manual Supplement)

| * kilometers: | 8000 | 16000 | 24000 | 32000 | 40000 | 48000 | 56000 | 64000 | 72000 | 80000 | 88000 | 96000 | 104000 | 112000 | 120000 | 128000 |
|--|------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|--------|--------|--------|--------|
| maintenance items: | 6 mo | 12 mo | 18 mo | 24 mo | 30 mo | 36 mo | 42 mo | 48 mo | 54 mo | 60 mo | 66 mo | 72 mo | 78 mo | 84 mo | 90 mo | 96 mo |
| replace engine oil & filter | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x |
| inspect engine air filter (1) | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x |
| lube locks, hinges & latches | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x |
| inspect lights, horns & wipers | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x |
| check coolant, brake & washer fluid levels | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x |
| inspect tire condition & pressure (2) | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x | x |
| replace cabin air filter | | x | | x | | x | | x | | x | | x | | x | | x |
| check transaxle fluid level | | | | x | | | | x | | | | | | | | x |
| change transaxle fluid ** | | | | | | | | | | | | x | | | | |
| inspect steer. gear box, linkage, suspension (3) | | x | | x | | x | | x | | x | | x | | x | | x |
| inspect ball joints & dust covers | | x | | x | | x | | x | | x | | x | | x | | x |
| inspect drive shaft and steering rack boots | | x | | x | | x | | x | | x | | x | | x | | x |
| inspect chassis nuts, for looseness or damage | | x | | x | | x | | x | | x | | x | | x | | x |
| inspect brake linings, drums pads & discs | | x | | x | | x | | x | | x | | x | | x | | x |
| inspect brake lines & hoses | | x | | x | | x | | x | | x | | x | | x | | x |
| perform complete brake service | | | | x | | | | x | | | | x | | | | x |
| inspect exhaust system for leaks or damage | | x | | x | | x | | x | | x | | x | | x | | x |
| Road test | | x | | x | | x | | x | | x | | x | | x | | x |
| replace super long life coolant (4) | | | | | | | | | | | | | | | | |
| replace cabin air filter | | x | | x | | x | | x | | x | | x | | x | | x |
| inspect fuel lines, vapour vent system | | | | x | | | | x | | | | x | | | | x |
| inspect gas tank bands and cap gasket | | | | x | | | | x | | | | x | | | | x |
| replace iridium spark plugs (5) | | | | | | | | | | | | | | | | |

(1) inspect as scheduled, visually check & clean with compressed air as needed. Replace at least every 48000km

(2) including spare, rotate as needed

(3) check for looseness, damage or leakage

(4) replace at 120 mo / 160000 km, thereafter every 60 months / 80000 km

(5) every 192000 km

* months or kilometers, whichever comes first

** not clear if this is required